

BobCat Composite
ASSEMBLY & OPERATION MANUAL

BVM BobCat Composite
RADIO CONTROL COMPONENTS
USING JR HIGH VOLTAGE EQUIPMENT

CONTROLS	QTY	SERVO TYPE	QTY			LEAD EXT
			Fuse	Booms	Wing	<i>ALL HD</i>
Ailerons	2	JR DS 8411 HV	2			18"
					2	12"
Elevators	1	JR DS 8711 HV		1		36"
			1			18"
Rudders	2	JR DS 9411 HV		2		18"
				1 (stab)		24"
			2			12"
Nose Steering	1	JR DS 821 HV				
Retract Valve	1	N/A				N/A
Flaps	2	JR DS 8411 HV	2			18"
					2	6"
E-Brake V2	1	JR DS 8911 HV				N/A
Battery	1	4000mAh				

NOTE: IF EQUIPMENT OTHER THAN JR IS USED, CONSULT THAT MANUFACTURER FOR SIMILAR COMPONENTS.

JR Heavy Duty servo arm to be used on elevator (comes standard with 8611A servo).

Optional: JR "MatchMaker" (#JRPA915) is very handy.
For Bench set-up

NOTE: As of 2015, most of these components are obsolete and not available. Consult your R/C manufacture for current and equivalent components. High voltage systems are now prevalent.